

GRAVELY *Technical* BULLETIN



BULLETIN NO. 959

DATE: May 8, 1962

TO: ALL OUTLETS

SUBJECT: 1. 50-Inch Rotary Mower: Lubrication and Operating Information
2. Replacement of Name Plates on Replacement Fan Housings
3. Dimensions of Dumping Scoop

50-INCH ROTARY MOWER: LUBRICATION AND OPERATING INFORMATION

Lubrication--The 50-inch Rotary Mower must be lubricated prior to delivery to the customer. It is not lubricated, with the exception of the Spindle Assemblies (which are permanently lubricated), at the factory. Use Mobilgrease MP for the Zerk Fittings (two of these are located on each Caster Assembly and one is located on the Main Drive Assembly); paint must be removed from these fittings prior to lubrication. Use approximately one-half-pound 140 weight Mobiloil to lubricate Main Drive assembly; fill to level of the Oil Level Plug only.

Operating-- When mowing in wet or very high grass, the Mower may become choked with cut grass. Advise your customers if this happens to remove the Mulcher, by unbolting it from the underside of the Deck.

Complete instructions will be available in about 10 days.

REPLACEMENT OF NAME PLATES ON REPLACEMENT FAN HOUSINGS

Field reports indicate that when a Fan Housing is changed, the Tractor loses its Nameplate, on which are stamped the Manufacturing Number and Serial Number. To make sure these vital identifications remain with the Tractor, remove the Nameplate from the old Fan Housing and attach it to the new Fan Housing. If the Nameplate is damaged, it can be returned to the factory in exchange for a new one.

DIMENSIONS OF DUMPING SCOOP

Following are dimensions, capacity and weight of the Dumping Scoop Attachment:

External Dimensions: 35-1/2" wide, 23" long, and 18" deep

Internal Dimensions: 29-1/2" wide, 15-1/2" long, and 10" deep

Capacity: 350 pounds Net Weight: 71 pounds