




ILLUSTRATED PARTS LIST

CIRCULAR SAW

Model Number 15687E1
 Effective Date 6-15-74
 Form Number 20824L1



ITEM NO.	PART NO.	DESCRIPTION
1	180122	Bolt, Hex 3/8-16 x 1
2	180181	Bolt, Hex 1/2-13 x 2
3	13150P1	Collar, Guard
4	10120A1	Rim, Assembly
5	13479P1	Blade, 18 In. Saw